



This Datasheet for the

IC670GBI002

24VDC Bus Interface Unit

<http://www.cimtecautomation.com/parts/p-14508-ic670gbi002.aspx>

Provides the wiring diagrams and installation guidelines for this GE Field Control module.

For further information, please contact Cimtec Technical Support at

1-866-599-6507

sales@cimtecautomation.com

Bus Interface Unit Installation Instructions


Installing the DIN Rail

The BIU Terminal Block must be mounted on a 7.5mm x 35mm DIN rail that has a conductive (unpainted) finish for proper grounding. When using multiple rail sections, be sure they are properly aligned. Mount the DIN rail at least 4.25 inches (10.80 cm) from a wireway or other obstruction *on the wiring side of the BIU*. Allow more space if I/O module wiring is very stiff.

Caution


This BIU has a metal grounding strip underneath the terminal block. It **must** be used with a grounded conductive DIN rail. It is **not** compatible with A versions of I/O Terminal Blocks, which do not have a metal grounding strip. Do not use this BIU terminal block with A version I/O terminal blocks; the resulting system would have poor noise immunity.

For added vibration resistance, the DIN rail should be installed on a panel using screws spaced approximately 6 inches (5.24cm) apart. For maximum vibration resistance, drill two holes for the BIU Terminal Block mounting ears as shown below. After mounting the terminal block on the DIN rail, install 3/8-inch (9.525mm) #6 screws (not supplied) through the mounting ears.




Installing the BIU Terminal Block


1. Tilt the BIU Terminal Block and position it over the rail, catching the rail behind the tabs in the terminal block.



2. Pivot the terminal block downward until the spring-loaded latches in the terminal block click into place.



3. Tighten the DIN rail clamp screw. Recommended torque is 4 in/lb to 6 in/lb.




Removing the BIU Terminal Block from the DIN Rail

1. Loosen the DIN rail clamp screw.
2. Insert a small flat-blade screwdriver into the upper latch and pry it outward. Then, pull up gently on the top of the terminal block to disengage the upper latch from the rail.
3. Keep gently pulling the top of the terminal block away from the rail. Insert the screwdriver into the lower latch and pry it outward to free the terminal block.


Connecting Terminal Blocks

Up to four I/O Terminal Blocks can be connected to a Bus Interface Unit. All I/O Terminal Blocks in a group must be connected either before or after BIU. The BIU must not be connected between I/O Terminal Blocks.



Before installing the BIU on its terminal block, install the connection cable to the next terminal block. A short connection cable, as illustrated below, is supplied with each I/O Terminal Block. Optional 21 inch (0.53 meter) cable is also available. Only one longer cable can be used per I/O station.

The illustration below shows cable connection between a BIU terminal block and an I/O Terminal Block. Make connections between I/O Terminal Blocks in the same manner. The connectors are keyed to assure proper installation.




After installing the cable, be sure it is firmly seated on both connectors.

GFK-0865G

Wiring the BIU Terminal Block

1. Connect an appropriate power source as shown below.



For BIU version IC670GBI102, if a DC supply is used the polarity is not important.

BIU version IC670GBI102 provides internal overvoltage protection. Terminal 4 is normally connected to frame ground (terminal 3) by a factory-installed jumper. If overvoltage protection is not required or is supplied upstream this feature can be disabled by removing the jumper, leaving pin 4 unconnected.

2. Use one AWG #14 (2.1mm²) or two AWG #16 (1.3mm²) wires per terminal. The wires into a terminal should be the same type and size. Wires must be copper conductors rated for 75 degrees C (167 degrees F) only. Suggested torque for the terminal screws is 9 in/lbs.
3. Connect the ground terminal to the conductive mounting panel with a 4-inch maximum length of AWG #14 (avg 2.1mm²) or larger wire. Use hardware such as star washers to ensure ground integrity.

Noise Immunity

If the installation might exceed the surge immunity specified in the *Bus Interface Unit User's Manual*, it is prudent to provide local transient protection as described in that manual.

System Grounding

All components of a control system and the devices it controls must be properly grounded. Each Terminal Block should be grounded in the manner described above. Control panels and enclosures should be bonded to the plant system ground per code.

Ground conductors should be connected in a tree fashion with all branches routed to a central earth ground point. This ensures that no ground conductor carries current from any other branch.


Inadequate grounding may compromise system integrity in the presence of power switching transients and surges.

Connecting the Communications Bus


If the BIU will be installed on a conventional single bus, make the Bus A connections only. If the BIU will be installed on a redundant (dual) bus, also connect Bus B. *Do not attach an external Bus Switching Module to a BIU.*

For bus connections, the maximum exposed length of unshielded wires should be 2 inches (5cm). Insulate each shield

drain wire with spaghetti tubing to prevent the Shield In and Shield Out wires from touching each other, or the signal wires.




1. Connect Serial 1 to the Serial 1 terminals of the previous device and the next device.
2. Connect Serial 2 to the Serial 2 terminals of the previous device and the next device.
3. Connect Shield In to Shield Out of the preceding device. Connect Shield Out to Shield In of the next device. If the BIU is the first device on a bus, Shield In can be left unconnected. If it is the last device on a bus, Shield Out can be left unconnected.



If the BIU is at either end of the bus (electrically), connect a 75, 100, 120, or 150-ohm terminating resistor across the Serial 1 and Serial 2 terminals for that bus. The *I/O System User's Manual* lists the correct impedance to use for different types of bus cable.

Note: If the BIU will be powered up when not connected to a properly terminated bus, connect a 75-ohm resistor across its Serial 1 and Serial 2 terminals to assure proper powerup.


For applications using 150 ohm cables, prefabricated cables are available in 15" (IC660BLC001) and 36" (IC660BLC003) lengths. These cables terminate in mating connectors that simplify wiring between I/O blocks. The 36" cable is recommended for TerminalBlock installations.



Prefabricated molded connectors with terminating resistors are available for 75 ohms (catalog number IC660BLM508) and 150 ohms (IC660BLM506). They can be used with conventional bus cable and with the cables with pre-molded connectors. Attach the prefabricated resistor to the female cable end.

Installing the BIU on its Terminal Block

1. Before installing a new Bus Interface Unit, remove the cable slot plug on the end of the module that will cover the connecting cable. The plug can be removed with pliers, or by pressing *out* from inside the module housing.
2. To install the BIU on the terminal block, position the module so that the cable slot in the module housing is over the connecting cable. Press the module down firmly.



Caution

Do not exert excessive force; it may damage the equipment.

3. If unusual resistance is met, remove the Bus Interface Unit. If power is applied, **DO NOT TOUCH THE CONNECTOR PINS!** Inspect the Terminal Block, and the connectors on the Terminal Block and on the Bus Interface Unit. Remove any obstacles and reinsert the Bus Interface Unit.
4. After placing the Bus Interface Unit onto the terminal block, tighten its screws to secure it. Maximum recommended torque is 9 in./lbs.

Removing the BIU from the Terminal Block


1. Loosen the Bus Interface Unit retaining screws.

Caution

Be sure screws are fully disengaged. Attempting to remove the module with screw(s) partially engaged may damage the equipment.

2. Pull the Bus Interface Unit module straight away from the Terminal Block.

Side View



Caution

Do not tilt the Bus Interface Unit to remove it. Removing the Bus Interface Unit at an angle may cause damage.

Removing/Installing Modules in the Station

Bus Interface Units IC670GBI002(F) and IC670GBI102A or later support hot insertion/removal of I/O modules whose catalog number suffix is J or above. Hot insertion/removal requires I/O Terminal Blocks IC670CHS101, 102, or 103. With these terminal blocks, modules can be inserted/removed without removing power to the I/O station or affecting other devices in the I/O station. External power to the module itself must be removed for hot insertion/removal. Hot insertion/removal can only be performed in non-hazardous locations.

I/O Terminal Blocks IC670CHS001, 002, and 003 do not support hot insertion/removal of modules. I/O Station power should be off when installing or removing modules.

Mixing IC670CHS10x terminal blocks with IC670CHS00x terminal blocks in the same I/O station is not recommended.

Instructions for Hazardous Locations

Warnings

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, and D or in non-hazardous locations only.

WARNING—Explosion Hazard—Substitution of components may impair suitability for Class I, Division 2.

WARNING—Explosion Hazard—Do not disconnect equipment unless power has been switched OFF or the area is known to be non-hazardous.

When in hazardous locations, turn off power before replacing or wiring modules. Do not remove or insert external modules with power applied. Personal injury, system malfunction and/or damage to the equipment may occur.

In non-hazardous locations, for personal safety field power should be off while removing or inserting a high-voltage I/O module. Avoid contact with module wiring and with the exposed connectors on the I/O Terminal Block.